

DCH DVR 6400 and DCH 6200 Installation Setup Using HD Component Cable

REMEMBER: With this setup, your TV must be set to whichever COMPONENT INPUT you connected the COMPONENT VIDEO cable into. You can change this on your TV remote or main menu. Examples of the input channel are: Input (1 or 2), Source, or Component (1 or 2). Once you have the TV on the correct video setting, you can change the cable station on the digital box using our provided remote.

